

KOALA

L I V I N G


Assembly Instruction

Product Name: Errol Charcoal and Vanilla Boucle Patterned Dining Chair


Product Id: 128147

Hardware List

- | | | | |
|---|---|-----------------------|-------|
| A |  | Allen Key | 1 pc |
| B |  | Allen Bolt
M8x55mm | 4 pcs |
| C |  | Allen Bolt
M8x45mm | 4 pcs |
| D |  | Spring
Washer | 8 pcs |
| E |  | Washer
Ø8mm | 8 pcs |



Part List



Seat
1 pc




Leg A
1 pc



Leg B
1 pc





Leg C
2 pcs




Note

1. Assemble the item on a soft, well-lit surface like cardboard or carpet.
2. For safety and efficiency, it's best to have two or more people assist with assembly to handle heavy parts safely and collaborate effectively.
3. Keep all packaging materials intact until assembly is complete.
4. Before assembling the item, carefully read all provided instructions.
5. Handle tools with care during assembly to prevent injuries.


1




2



3



4



- Place the chair on an even surface.
- Put a load of approx. 60KG on to the seat.
- Adjust until all 4 legs are level - before you carefully tighten the screws.
- NOTE! The screws must be tightened after a period of use, and thereafter as required

